

Glass And Plastic Cleaner

Cleans windows, mirrors, glass display cases, CRT screens, TV screens, office equipment, Plexiglas®, plastic, painted surfaces, counters, tabletops, vinyl upholstery and any surface not damaged by water. Removes dirt, fingerprints, grease, smoke film and hair spray. Non- ammoniated formula evaporates fast to help prevent streaking or filming. Antistat formula.

- Cleans without harming sensitive plastic surfaces.
- Evaporates fast to help prevent streaking.
- Helps eliminate fog on glass and mirrors.

Technical Specifications

Appearance	Clear
Dilution Rate	RTU
Color	Blue
Scent	Mild alcohol
Non Volatile Matter	0.00 - 0.50%
pH @ 25 deg. C	7.00 - 8.00

HMIS (Concentrate/RTU)

Flammability = 3 Health = 1 Reactivity = 0

Directions

1. Use trigger sprayer, holding 6-8 inches from surface. Always work from bottom up.
2. Wipe dry with towel or cloth.

SPECIAL INSTRUCTIONS: When used on office machinery and data processing equipment (computers), always spray on paper towel or clean cloth and then wipe area to be cleaned. Never spray directly on any surface where working office machinery or computer parts would be exposed to this product.



Safety

See material safety data sheet and product for safety information, handling and proper use.

Availability

HIL0012106	4 - 1 Gallon Containers
HIL0012109	1 - 55 Gallon Drum
HIL0100204	12 - 1 Quart Bottles